


Visual Display

Main Board


Logic Controller

AR7525-BP General Diagram




* Aux. relays can be set individually to follow either input signal or output (by default, it follows input)


AR7525-LG (Logic Module)



AR7525-PS (Power Supply & Relay)



LED Module



Annunciator Main Board Connection

